

Air Condition Line Set Bender Kit

Manual:

Read all directions, hazard and precautionary statements before using this product.

The bender kit mandrels have been designed to make one bend at a time. Make sure the mandrels are inserted at least 30 cm (12 inch) past the point you will start bending the linesets. For every tight bends, bend a little back open the bent lineset to ease the retraction of the bender kit mandrell(s).

When installing a complex lineset with many bends, twists or elbows, please respect following recommendations to reduce the cumulative drag on the mandrels and make it easier to withdraw them once all the bends have been done:

1. Insert the bender kit mandrel(s) at least 30 cm (12 inch) past the point you will start bending your first bend, which should be furthest away from the condenser (outdoor unit).
2. Withdraw the mandrel(s) until the next bend, ensuring that again at least 30 cm (12 inch) remain *past the bending point of your next bend (namely *closer to the previous bend).
3. Repeat the process until you have made all bends, the last one being closest to the condenser (outdoor unit).

Ignoring above instructions may lead to difficulty in withdrawing the mandrels and could result in deforming them or breaking them off.

Code No.	Colour	Diameter	For tube size
<input type="checkbox"/> INB14R	Red	4mm	1/4"
<input type="checkbox"/> INB38G	Green	7mm	3/8"
<input type="checkbox"/> INB12Y	Yellow	9mm	1/2"
<input type="checkbox"/> INB58B	Blue	12mm	5/8"
<input type="checkbox"/> INB34P	Purple	16mm	3/4" (NOT IN THE KIT)

Advantages:

- No need for springs or heavy and expensive equipment.
- Flexible construction.
- No more faulty pipe bendings.
- Reusable product made of durable material.
- Only for soft copper.
- 4 sizes for most MiniSplit/VRF applications.
- Rod length:4m

